NORMAL TAKEOFF 1. Flaps
ENROUTE CLIMB 1. Airspeed
CRUISE 1. MixtureLEAN AS REQUIRED 2. Engine InstrumentsCHECK
DESCENT 1. Fuel Selector ValveBOTH 2. MixtureAS REQUIRED
BEFORE LANDING 1. Fuel Selector Valve
NORMAL LANDING 1. Flaps
AFTER LANDING 1. Flaps
SHUTDOWN 1. Avionics Master

N959HC CE-172M CHECKLIST

BEFORE START 1. Passenger Safety Brief	ON BOTH OFF
ENGINE START	40

	ENGINE START	
1	Rotating Beacon	ON
2	2. Mixture	RICH
3	3. Throttle	1/8" OPEN
4	L Carb Heat	OFF
5	5. Brakes Set	SET
6	S. Master Switch	ON
	7. Primer	
8	3. Prop Area	CLEAR
Ç	9. Ignition Switch	START
	0. Throttle	
	1.Oil Pressure	

AFTER START	
1. Flaps	
2. Avionics Master	ON
3. Mixture	1/2in LEAN FOR TAXI
4. Taxi Light	
5. ATIS	

TAXI	
1. Doors	LOCKED
2. Area	CLEAR
3. Yoke	AFT FOR TAXI
4. Brakes	

BEFORE TAKEOFF CHECK	
1. Nose Wheel	STRAIGHT
2. Flight Controls	FREE AND CORRECT
3. Fuel Selector Valve	BOTH
	SET FOR TAKEOFF
5. Mixture	RICH
6. Throttle	1700 RPM
a. Mag Check	125 RPM MAX - 50 DIF
b. Carb Heat	CHECK DROP
c. Engine Instruments	CHECK
d. Ammeter	CHECK
	CHECK
	IDLE CHECK / THEN 800 - 1000 RPM
8. Flight Instruments	SET
9. Radios	SET
	ON
	NOTED

EMERGENCY PROCEDURES

ENGINE FAILURE

- 1. Best Glide 70 KIAS
- 2. Fuel ON.
- 3. Mixture RICH.
- 4. Throttle OPEN.
- 5. Carb Heat ON.
- 6. Ignition Switch ON
- 7. Primer IN and LOCKED

FORCED LANDING

- Airspeed 70 KIAS Flaps UP, 60 KIAS Flaps DOWN
- 2. Fuel Valve OFF
- 3. Mixture IDLE CUTOFF
- 4. Ignition Switch OFF
- 5. Radios/Flaps AS REQUIRED
- 6. Master Switch OFF
- 7. Seatbelts TIGHTEN
- 8. Doors UNLATCHED
- 9. Touchdown SLIGHTLY TAIL LOW

ELECTRICAL FIRE INFLIGHT

- 1. Master Switch OFF
- 2. All Switches OFF (except ignition).
- 3. Vents and Windows CLOSED.
- 4. Use Extinguisher if Needed.
- 5. Master Switch ON.
- 6. Circuit Breakers CHECK

ENGINE FIRE IN FLIGHT

- 1. Mixture IDLE CUTOFF
- 2. Fuel Shutoff Valve OFF
- 3. Master Switch OFF
- 4. Cabin Air/Heat OFF
- 5. Airspeed >85 KIAS
- 6. Forced Landing EXECUTE
- 7. Radios/Electrical Switches ON one at a time
- 8. Vents and Windows OPEN when fire is out

FREQUENCIES

Twin Oaks CTAF 123.05 Portland App 118.1/126.0 Clearance 119.95

CTAF 123.00 ASOS 135.67

McMinnville

Hillsboro

Tower 119.3 ATIS 127.65 Ground 121.7 Aurora

Tower 120.35 ATIS 118.52 GROUND 119.15

West Practice Area 122.75

N959HC CE-172M

N959HC CF-172M

N959HC CE-1	72IVI
Speeds	
V _{S0} Stall in Landing Config.	36
V _S Stall Clean	43
V _X Best Angle	60
V _Y Best Rate	75 (sea level) 65 (at 10,000')
V _{REF} Flaps Up	65
V _{REF} Flaps Down	55-65
V _{FE} Flaps Extended	85
V _A Maneuvering Speed	100
V _{NO} Max Structural Cruise	129
V _{NE} Never Exceed	160
V _G Best Glide	70 (flaps up) 60 (flaps down)
Short Field Takeoff (Flaps Up)	60 (no flaps)
Short Field Approach	60 (40° flaps)
NOTE: Avoid slips with full flaps; it may	cause the elevator to oscillate.
Fuel	
Total Capacity	54 US GAL
Usable	50 US GAL
Engine	-
Horsepower	150 at 2700 RPM
Oil Capacity (minimum)	8 quarts (6 min)
Fuel Burn at 75% power at 5000ft	8.1 GPH
Weight	-
Max Gross Weight	2300 lbs

All information taken from the respective owner's manuals and supplemental data.

This is for reference only and NOT to be used for flight planning.