NORMAL TAKEOFF 1. Flaps	OFF FULL WHEEL (55 MPH)
ENROUTE CLIMB 1. Airspeed	75-85 MPH I AS REQUIRED
CRUISE 1. MixtureLEA 2. Engine Instruments	
DESCENT 1. Fuel Selector Valve 2. Mixture	
BEFORE LANDING 1. Fuel Selector Valve	RICH ON
NORMAL LANDING 1. Flaps	AS DESIRED PS DOWN 70 MPH
AFTER LANDING 1. Flaps	OFF
SHUTDOWN 1. Avionics Master 2. Electrical Switches 3. Throttle 4. Mixture 5. Magnetos 6. Master Switch 7. Control Lock 8. Tie Downs 9. Post Flight Inspection	OFF1000 RPMIDLE CUTOFFOFFOFFSECURE

N66119 CE-150M CHECKLIST

BEFORE START 1. Passenger Safety Brief	COMPLETE ON ON
ENGINE START 1. Rotating Beacon	O

ENGINE START	
1. Rotating Beacon	ON
2. Mixture	RICH
3. Throttle	1/8" OPEN
4. Carb Heat	OFF
5. Brakes	
6. Master Switch	ON
7. Primer	
8. Prop Area	CLEAR
9. Ignition Switch	START
10. Throttle	800 RPM
11.Oil Pressure	CHECK

AFTER START	
1. Flaps	UP
2. Avionics Master	ON
3. Mixture	1/2in LEAN FOR TAXI
4. Wing Tip Lights	
5. ATIŠ	

TAXI	
1. Doors	LOCKED
2. Area	CLEAR
3. Yoke	AFT FOR TAXI
4. Brakes	CHECK

BEFORE TAKEOFF CHECK	
1. Nose Wheel	STRAIGHT
2. Flight Controls	FREE AND CORRECT
	BOTH
4. Trim	SET FOR TAKEOFF
5. Mixture	RICH
6. Throttle	1700 RPM
a. Mag Check	125 RPM MAX - 50 DIF
b. Carb Heat	CHECK DROP
c. Engine Instruments	CHECK
d. Ammeter	CHECK
7. Throttle	IDLE CHECK / THEN 800 - 1000 RPM
8. Flight Instruments/G5	SET
	SET

10.Lights.....ON 11.Time.....NOTED

EMERGENCY PROCEDURES

ENGINE FAILURE

- 1. Best Glide 70 MPH
- 2. Fuel ON.
- 3. Mixture RICH.
- 4. Throttle OPEN.
- 5. Carb Heat ON.
- 6. Ignition Switch ON
- 7. Primer IN and LOCKED

FORCED LANDING

- 1. Airspeed 70 MPH Flaps UP, 65 MPH Flaps DOWN
- 2. Fuel Valve OFF
- 3. Mixture IDLE CUTOFF
- 4. Ignition Switch OFF
- 5. Radios/Flaps AS REQUIRED
- 6. Master Switch OFF
- 7. Seatbelts TIGHTEN
- 8. Doors UNLATCHED
- 9. Touchdown SLIGHTLY TAIL LOW

ELECTRICAL FIRE INFLIGHT

- 1. Master Switch OFF
- 2. All Switches OFF (except ignition).
- 3. Vents and Windows CLOSED.
- 4. Use Extinguisher if Needed.
- 5. Master Switch ON.

- 6. Circuit Breakers CHECK
- 7. Radios/Electrical Switches ON one at a time
- **ENGINE FIRE IN FLIGHT**
- 1. Mixture IDLE CUTOFF
- 2. Fuel Shutoff Valve OFF
- 3. Master Switch OFF
- 4. Cabin Air/Heat OFF
- 5. Airspeed >100MPH
- 6. Forced Landing EXECUTE

8. Vents and Windows OPEN when fire is out

FREQUENCIES

Twin Oaks CTAF 123.05 Portland App 118.1/126.0 Clearance 119.95

Hillsboro

Tower 119.3 ATIS 127.65 Ground 121.7 **Aurora**

Tower 120.35 ATIS 118.52 **GROUND 119.15**

McMinnville

CTAF 123.00

ASOS 135.67

West Practice Area 122.75

N66119 CE-150M

N66110 CE 150M

N66119 CE-18	50M
Speeds	
V ₅₀ Stall in Landing Config.	48
V _S Stall Clean	56
V _X Best Angle	70
V _Y Best Rate	78 (sea level) 70 (at 10,000')
V _{REF} Flaps Up	75
V _{REF} Flaps Down	70
V _{FE} Flaps Extended	100
V _A Maneuvering Speed	109
V _{NO} Max Structural Cruise	120
V _{NE} Never Exceed	162
V _G Best Glide	70 (flaps up)
Short Field Takeoff (Flaps Up)	70 (no flaps)
Short Field Approach	65-70 (40° flaps)
NOTE: Avoid slips with full flaps; it may c	ause the elevator to oscillate.
Fuel	
Total Capacity	26 US GAL
Usable	22.5 US GAL
Engine	-
Horsepower	100 at 2700 RPM
	6 quarts (4 min)
Oil Capacity (minimum)	0 quarts (4 min)

All information taken from the respective owner's manuals and supplemental This is for reference only and NOT to be used for flight planning.

1600 lbs

Max Gross Weight