NORMAL TAKEOFF 1. Flaps	OFF FULL SE WHEEL (60 MPH)
ENROUTE CLIMB 1. Airspeed	80-90 MPH AN AS REQUIRED
CRUISE 1. MixtureL 2. Engine Instruments	
DESCENT 1. Fuel Selector Valve 2. Mixture	
BEFORE LANDING 1. Fuel Selector Valve	RICH ON
NORMAL LANDING 1. Flaps	AS DESIRED PS DOWN 65-75 MPH
AFTER LANDING 1. Flaps	OFF
SHUTDOWN 1. Avionics Master 2. Electrical Switches 3. Throttle 4. Mixture 5. Magnetos 6. Master Switch 7. Control Lock 8. Tie Downs 9. Post Flight Inspection	OFF1000 RPMIDLE CUTOFFOFFOFFINSTALLSECURE

N65KD CE-172M CHECKLIST

	FORE START	
1.	Passenger Safety Brief	COMPLETE
	Seat Belts	
3.	Fuel Selector Valve	BOTH
4.	Radios and Electrical Equipment	OFF
5.	Circuit Breakers	CHECKED

ENGINE START	
Rotating Beacon	ON
2. Mixture	RICH
3. Throttle	1/8" OPEN
4. Carb Heat	OFF
5. Brakes	SET
6. Master Switch	ON
7. Primer	
8. Prop Area	CLEAR
9. Ignition Switch	START
10. Throttle	800 RPM
11.Oil Pressure	

AFTER START	
1. Flaps	UP
2. Avionics Master	ON
3. Mixture	1/2in LEAN FOR TAXI
4. Taxi Light	
5. ATIS	COPY

TAXI	
1. Doors	LOCKED
2. Area	CLEAR
3. Yoke	AFT FOR TAXI
4. Brakes	CHECK

BEFORE TAKEOFF CHECK	
1. Nose Wheel	STRAIGHT
2. Flight Controls	FREE AND CORRECT
3. Fuel Selector Valve	BOTH
4. Trim	SET FOR TAKEOFF
5. Mixture	RICH
6. Throttle	1700 RPM
a. Mag Check	125 RPM MAX - 50 DIF
b. Carb Heat	CHECK DROP
c. Engine Instrumentsd. Ammeter	CHECK
7. ThrottleIDLE	CHECK / THEN 800 - 1000 RPM
8. Flight Instruments/G5	SET
9. Radios	SET
10.Lights	ON

EMERGENCY PROCEDURES

ENGINE FAILURE

- 1. Best Glide 75 MPH
- 2. Fuel ON.
- 3. Mixture RICH.
- 4. Throttle OPEN.
- 5. Carb Heat ON.
- 6. Ignition Switch ON
- 7. Primer IN and LOCKED

FORCED LANDING

- 1. Airspeed 75 MPH Flaps UP, 70 MPH Flaps DOWN
- 2. Fuel Valve OFF
- 3. Mixture IDLE CUTOFF
- 4. Ignition Switch OFF
- 5. Radios/Flaps AS REQUIRED
- 6. Master Switch OFF
- 7. Seatbelts TIGHTEN
- 8. Doors UNLATCHED
- 9. Touchdown SLIGHTLY TAIL LOW

ELECTRICAL FIRE INFLIGHT

- 1. Master Switch OFF
- 2. All Switches OFF (except ignition).
- 3. Vents and Windows CLOSED.
- 4. Use Extinguisher if Needed.
- 5. Master Switch ON.
- 6. Circuit Breakers CHECK

ENGINE FIRE IN FLIGHT

- 1. Mixture IDLE CUTOFF
- 2. Fuel Shutoff Valve OFF
- 3. Master Switch OFF
- 4. Cabin Air/Heat OFF
- 5. Airspeed >100MPH
- 6. Forced Landing EXECUTE
- 7. Radios/Electrical Switches ON one at a time
- 8. Vents and Windows OPEN when fire is out

FREQUENCIES

Twin Oaks CTAF 123.05 Portland App 118.1/126.0

Clearance 119.95

Hillsboro

Tower 119.3 ATIS 127.65 Ground 121.7 **Aurora**

Tower 120.35 ATIS 118.52 **GROUND 119.15**

McMinnville

CTAF 123.00

ASOS 135.67

West Practice Area 122.75

N65KD CE-172M

N65KD CE-172	IVI
Speeds	
V _{S0} Stall in Landing Config.	49
V _S Stall Clean	57
V _X Best Angle	68
V _Y Best Rate	91 (sea level) 80 (at 10,000')
V _{REF} Flaps Up	70-80
V _{REF} Flaps Down	65-75
V _{FE} Flaps Extended	100
V _A Maneuvering Speed	112
V _{NO} Max Structural Cruise	145
V _{NE} Never Exceed	182
V _G Best Glide	75 (flaps up) 70 (flaps down)
Short Field Takeoff (Flaps Up)	68 (no flaps)
Short Field Approach	70 (40° flaps)
NOTE: Avoid slips with full flaps; it may cau	use the elevator to oscillate.
Fuel	

Fuel	
Total Capacity	42 US GAL
Usable	38 US GAL
Engine	
Horsepower	160 at 2700 RPM
Oil Capacity (minimum)	8 quarts (6 min
Fuel Burn at 75% power at 5000ft	8.1 GPH
Weight	
Max Gross Weight	2300 lbs

All information taken from the respective owner's manuals and supplemental This is for reference only and NOT to be used for flight planning.